

3M[™] Full Facepiece Reusable Respirator FF-600 Series

Technical datasheet

Product description

The 3M[™] Full Facepiece Reusable Respirator FF-600 Series can be used with approved 3M[™] DT-Series filters^{*} with a 40mm (EN 148-1) thread, or they can be used as part of an approved powered air respirator system using the appropriate breathing tube. Both combinations protect against gases, vapours and/or particulates depending on your individual needs.

Please note, the 3M[™] Full Facepiece Reusable Respirator FF-600 Series, was previously named the Scott[™] Vision[™] Reusable Full Mask, RFF4000 or the Scott[™] Vision[™] Reusable Full Mask, FM4 for the PAPR version.

*Filters previously from the Scott Safety Pro2000 range

Key features

- Approved to EN 136:1998 Class 2 and EN 12942:1998 + A2:2008 TM3 when used as part of a powered air respirator system
- Speech diaphragm
- Side port filter or breathing tube attachment
- Three sizes FF-601 (Small) FF-602 (Medium) FF-603 (Medium/ Large)
- Spectacle kit available
- ▶ Facepiece weight: approx. 550 grams

Assigned Protection Factors

3M [™] Full Facepiece Reusable Respirator FF-600 Series with:	Assigned Protection Factor*
P1 Particulate Filters **	4
P2 Particulate Filters**	10
P3 Particulate Filters**	40
Class 1 Gas and Vapour Filters**	20 or 1000ppm (whichever is lower)
Class 2 Gas and Vapour Filters**	20 or 5000ppm (whichever is lower)
3M [™] Powered Air Turbo PF-602E 3M [™] Versaflo [™] Powered Air Turbo TR-602E 3M [™] Versaflo [™] Powered Air Turbo TR-802E	40

*For further information on Assigned Protection Factors (APFs) see HSE document HGS53 or alternatively contact 3M.

Please refer to EN 529:2005 and National workplace protection guidance for application of these numbers in the workplace. Please contact 3M for further information.

** with approved 3M[™] DT-Series filters



Standards and approvals

The 3M^{\sim} Full Facepiece Reusable Respirator FF-600 Series have been tested to EN 136:1998 Class 2 and EN 12942:1998 + A2:2008 TM3.

The Certificates and Declarations of Conformity are available at the following website: www.3M.com\Respiratory\certs

Key use limitation

- 1. This respirator does not supply oxygen. Do not use in atmospheres containing less than 19.5% oxygen.
- 2. Do not use for respiratory protection against atmospheric contaminants that have poor warning properties or are unknown or immediately dangerous to life and health (IDLH) or against contaminants which generate high heats of reaction with chemical filters.
- 3. Do not misuse, alter, modify or repair this product.
- 4. Do not use with beards or other facial hair that prevent direct contact between face and edge of the respirator.
- 5. Do not use with unknown concentrations of contaminants.
- 6. Leave the work area immediately and check the integrity of the respirator and replace face mask if:

a. Damage has occurred or is apparent

b. Breathing becomes difficult or increased breathing resistance occurs

- c. Dizziness or other distress occurs
- d. You taste or smell the contaminant or an irritation occurs

7. Use strictly in accordance with respirator and filter user instruction leaflet.

For full use limitations please refer to the product user instructions.

3M[™] DT-Series Filters options*

Note: Filters previously from the Scott Pro2000 range

	Filter
	3M [™] Particulate Filter PF10 P3 R D DT-1135E
	3M [™] Particulate Filter PFR10 P3 R D DT-1235E (Reduced Opening)
	3M™ Combination Filter CF22 A2P3 R D DT-4031E
	3M [™] Combination Filter CF22 B2P3 R DT-4032E
	3M [™] Combination Filter Cartridge CF22 A2B2P3 R D DT-4035E
	3M [™] Combination Filter CF32 A2B2E2K2P3 R D DT-4045E
	3M [™] Combination Filter CF22 A2B2E1P3 R D DT-4036E
	3M [™] Combination Filter CF32 A2B2E2K2HgP3 R D DT-4046E
	3M [™] Combination Filter CF32 AXB2P3 R D DT-4048E
	3M [™] Gas and Vapour Filter GF22 A2 DT-4001E
	3M [™] Gas and Vapour Filter GF22 A2B2 DT-4005E
	3M [™] Gas and Vapour Filter GF32 A2B2E2K2 DT-4006E
	3M [™] Gas and Vapour Filter GF32 AX DT-4007E
	3M [™] Combination Filter CF32 AXP3 R D DT-4047E
	3M [™] Combination Filter CF32 Reactor HgP3 R D DT-4049E
	3M [™] Combination Filter CF32 A2P3 R D DT-4041E
	3M [™] Combination Filter CFR32 Reactor HgP3 R D DT-4149E (reduced opening)
	3M [™] Combination Filter CFR32 A2B2E2K2P3 R D DT-4145E, (reduced opening, foil bag)

* Refer to 3M[™] Powered Air Turbo PF-602E, 3M[™] Versaflo[™] TR-602E and 3M[™] Versaflo[™] TR-802E Technical Datasheets for filters approved as part of these powered air respirator systems.

3M[™] Breathing tube options

Breathing tube	3M [™] Powered Air Turbo PF-602E	3M [™] Versaflo [™] Powered Air Turbo TR-602E	3M [™] Versaflo [™] Powered Air Turbo TR-802E
SS-BT-55	Yes	N/A	N/A
SS-BT-55L	Yes	N/A	N/A
BT-54	N/A	Yes	Yes

Cleaning and storage

Cleaning is recommended when necessary.

If during use the equipment may have become contaminated by hazardous substances, the contamination must be identified and properly removed or the contaminated components must be replaced before next use.

Disposal of the contaminated components must be carried out in accordance with local regulatory requirements.

1. Inspect the equipment for worn or ageing or damaged components.

- 2. Carefully wipe the facemask clean with a warm water solution containing a mild detergent. The facemask may also be wiped with 3M[™] Cleaning Wipes, 105.
- 3. If necessary, wash the outside of the breathing hose carefully using warm water solution containing a mild detergent. Ensure the breathing hose connections are free from all dirt or debris that could prevent an effective seal with the blower.
- 4. Once clean all components must be left to dry naturally.

3M[™] Full Facepiece Reusable Respirator FF-600 Series

Materials

Component	Material
Facemask	Silicone
Inner mask	Thermoplastic elastomer
Head harness	EPDM
Visor	Polycarbonate

Shelf life

Shelf life: 5 year from production date when stored at storage conditions described on packaging.

The shelf life as defined above remains a indicative and maximum data, subject to many external and non-controllable factors. It may never be interpreted as a warranty. Always check that all mask components are in good condition before use

Spare parts

Part Number	Description
FF-600-01	Inhale valve
FF-600-02	Exhalation Valve Assembly
FF-600-04	Polynet Head Harness
FF-600-05	Nose Cup Assembly, Small / Medium
FF-603-05	Nose Cup Assembly, Large
FF-600-06	Front Cover
FF-600-07	Speech Diaphragm Assembly
FF-601-09	Visor Frame Assembly, Small
FF-602-09	Visor Frame Assembly, Medium
FF-603-09	Visor Frame Assembly, Large
FF-600-11	Inhalation Valve Seat Set
FF-600-12	Front fitting gasket
FF-600-20	Spectacle kit
FF-600-21	Spectacle kit 52mm
FF-600-41	Head Harness Assembly
FF-600-42	Buckle and roller pack
FF-600-43	Head Harness Clips
FF-600-44	Head Harness Hinges
FF-600-925	Standard visor
FF-600-926	Visor peel-offs

TECHNICAL STATEMENT

Technical Information: The technical information, guidance, and other statements contained in this document or otherwise provided by 3M are based upon records, tests, or experience that 3M believes to be reliable, but the accuracy, completeness, and representative nature of such information is not guaranteed. Such information is intended for people with knowledge and technical skills sufficient to assess and apply their own informed judgment to the information. No license under any 3M or third party intellectual property rights is granted or implied with this information.

Product Selection and Use: Many factors beyond 3M's control and uniquely within user's knowledge and control can affect the use and performance of a 3M product in a particular application. As a result, customer is solely responsible for evaluating the product and determining whether it is appropriate and suitable for customer's application, including conducting a workplace hazard assessment and reviewing all applicable regulations and standards (e.g., OSHA, ANSI, etc.). Failure to properly evaluate, select, and use a 3M product in accordance with all applicable instructions and with appropriate safety equipment, or to meet all applicable safety regulations, may result in injury, sickness, death, and/or harm to property.

Warranty, Limited Remedy, and Disclaimer: Unless a different warranty is specifically stated on the applicable 3M product packaging or product literature (in which case such warranty governs), 3M warrants that each 3M product meets the applicable 3M product specification at the time 3M ships the product. 3M MAKES NO OTHER WARRANTIES OR CONDITIONS, EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTY OR CONDITION OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE, OR ARISING OUT OF A COURSE OF DEALING, CUSTOM, OR USAGE OF TRADE. If a 3M product does not conform to this warranty, then the sole and exclusive remedy is, at 3M's option, replacement or repair of the 3M product or refund of the purchase price. Warranty claims must be made within one (1) year from the date of 3M's shipment.

Limitation of Liability: Except for the limited remedy stated above, and except to the extent prohibited by applicable law, 3M will not be liable for any loss or damage arising from or related to the 3M product, whether direct, indirect, special, incidental, or consequential (including, but not limited to, lost profits or business opportunity), regardless of the legal or equitable theory asserted, including, but not limited to, warranty, contract, negligence, or strict liability.

Disclaimer: 3M industrial and occupational products are intended, labeled, and packaged for sale to trained industrial and occupational customers for workplace use. Unless specifically stated otherwise on the applicable product packaging or literature, these products are not intended, labeled, or packaged for sale to or use by consumers (e.g., for home, personal, primary or secondary school, recreational/sporting, or other uses not described in the applicable product packaging or literature), and must be selected and used in compliance with applicable health and safety regulations and standards (e.g., OSHA, ANSI), as well as all product literature, user instructions, warnings, and other limitations, and the user must take any action required under any recall, field action or other product use notice. Misuse of 3M industrial and occupational products may result in injury, sickness, death, or property damage. For help with product selection and use, consult your on-site safety professional, industrial hygienist, or other subject matter expert. For additional product information, visit www.3M.com.

Personal Safety Division 3M United Kingdom PLC 3M Centre Cain Road, Bracknell Berkshire RG12 8HT t: 0870 60 800 60 www.3M.co.uk/PPEsafety

3M Ireland Limited The Iveagh Building The Park, Carrickmines Dublin 18 t: 1800 320 500

